

BUFFALO BAG

HANDCRAFTED LEATHER

Mounting instructions saddlebag bracket "Easy Fit" für HD Softail (2018-2021) & Cruiser (2022-)



Scope of supply:

- 1x Saddlebag bracket "Easy Fit"
- 2x Bungee Nut 3/8"
- 1x Screw 3/8" x 16 UNC x 2 1/2"
- 2x Screw 3/8" x 16 UNC x 1 3/4"
- 2x Grub screw 3/8 x 16 UNC x 1 3/4"
- 6x Hexagon screw VA 5x20
- 6x Nut 5mm, self-locking
- 12x Washer 5mm



Step 1: First loosen the two screws in the centre of the fender struts. Please note that there are different hole spacings for the different models. We also offer different brackets for the different distances. The two original screws are not reused, but please keep them in case you want to remove the bracket again.

Step 2: The two bungee nuts must now be attached to the fender. There are two options for mounting them.

- First variant: Take the two hexagon socket screws and screw them through the fender from behind. At the front you will now see the two threads onto which you screw the two bungee nuts. Please also use a commercially available threadlocker to secure the bungee nuts..
- Second variant: The scope of supply also includes two grub screws. First attach the bungee nuts to these pins (also use threadlocker) and screw these pins with the bungee nuts into the threads of the fender struts from the front. This is certainly the simpler option..
- Note: A longer hexagon bolt is also included in the scope of supply. Please use this if you have installed a sissy bar on your motorbike. This longer bolt is screwed in at the rear..

Step 3: Now determine the position of the bracket at the saddlebag. Our bags have a sewn-in aluminium plate on the back so that the bag can be screwed on specifically for your motorbike and at the desired height. Please hold the bag against your motorbike, select the desired position and mark the holes on the bag. The easiest way to do this is with a second person. Now drill the marked holes through our bag using a 5mm drill bit. To attach the bracket to the bag, please use the 5x20 hexagon screws, the washers and the self-locking nuts..

Step 4: The bracket is then hooked into the bungee nuts. Please check in advance that the lock plates are firmly screwed to the bracket. The bracket can then be hooked in and locked..

Note: Please always check that all screws are tight before driving and retighten them if necessary.



Bungee-Nuts with grub screw



Hooked bracket in the
Bungee-Nuts



Mounted Saddlebag