



## Victory saddlebag bracket

### Packing list and instructions

#### Scope of supply:

- 1x saddlebag bracket
- 2x Allen screw M8x70 (ISO 7380)
- 2x Allen screw M8x80 (ISO 7380)
- 2x Allen screw M8x30 (ISO 7380)
- 2x self-locking nut M8
- 4x washer 8,4
- 2x black spacer 5mm
- 2x black spacer 12mm
- 2x black spacer 30mm Victory Vegas / Vegas 8-Ball / Vegas High Ball / Kingpin / Jackpot / Boardwalk / Hammer / Hammer S / Hammer 8-Ball
- 2x black spacer 22mm Victory Judge



#### Step 1:

Loosen the two serial screws at your Victory

#### Step 2:

Hold the saddlebag bracket at your bike and check out; which spacers you'll have to use. In order to do that, the delivery includes 3 different sizes of spacers. A Sissy Bar or a luggage rack can be mounted with the bracket as well, when using the corresponding spacers.



#### Step 3:

Now mount the chosen combination of bracket, screw and spacer to

#### Step 4:

The screws 8x30 are for the mounting of the bag to the bracket.

#### Step 5: IMPORTANT!

Check periodically if the bag respectively the bracket fits firmly and, if necessary, tighten all screws again.

