



## Mounting instruction Saddlebag „Chicago with with sturdy metal bracket

Fits the Harley Davidson Dyna Street Bob as well as other Dyna models  
(e.g. FXD Super Glide 1996-2005, FXDC Super Glide Custom 2006- ,  
FXDF Fat Bob 2008-, FXDL Low Rider 1996-2014, FXDWG Wide Glide 1996- ,  
FXDX/T Super Glide Sport 1996-2005) with SOLO SEAT, where the pillion footrests are not  
fitted.

### Scope of supply:

- 1x Black leather saddlebag 7 litres
- 1x metal bracket without screws
- 2x Hexagon screw 6x16mm
- 4x Washer
- 2x Nut M6 self-locking



Fig.1

The metal holder is attached to the 3 existing screw connections on the belt guard. The existing fastening screws are used.



Fig.2

Once the metal holder has been fitted to the swing arm, position the bag on the on the bracket (e.g. with double-sided adhesive tape). Sit on the motorbike and check the clearance by compressing the shock absorbers.

**Before you drill the necessary holes in the back of the saddlebag, it is very important to leave enough space between the shock absorber and the primary drive so that the shock absorbers/swingarms can compress.**



Hansen Styling Parts  
Dorfstr. 9  
24247 Mielkendorf  
Tel.: 0049-4347-706970  
Fax.: 0049-4347-3201  
info@hansen-styling-parts.de  
www.hansen-styling-parts.de  
www.buffalo-bag.com