


Mounting instruction sturdy metal bracket


Fits the Harley Davidson Dyna Street Bob as well as other Dyna models (e.g. FXD Super Glide 1996-2005, FXDC Super Glide Custom 2006-, FXDF Fat Bob 2008-, FXDL Low Rider 1996-2014, FXDWG Wide Glide 1996-, FXDX/T Super Glide Sport 1996-2005) with SOLO SEAT, where the pillion footrests are not fitted.

Scope of supply:

1x metal bracket without screws 2x Hexagon screw 6x16mm 4x Washer 2x Nut M6 self-locking









Dorfstr. 9 24247 Mielkendorf Tel.: 0049-4347-706970 Fax.: 0049-4347-3201 info@hansen-styling-parts.de www.hansen-styling-parts.de www.buffalo-bag.com



Once the metal holder has been fitted to the swing arm, position the bag on the on the bracket (e.g. with double-sided adhesive tape). Sit on the motorbike and check the clearance by compressing the shock absorbers.

Before you drill the necessary holes in the back of the saddlebag, it is very important to leave enough space between the shock absorber and the primary drive so that the shock absorbers/swingarms can compress.