

BUFFALO BAG

HANDCRAFTED LEATHER

Mounting instructions saddlebag bracket "Easy-Fit" for HD Softail Slim and Blackline



Scope of supply:

- 1x Saddlebag bracket "Easy Fit"
- 2x Bungee Nut 3/8"
- 1x Screw 3/8" x 16 UNC x 2 1/2"
- 2x Screw 3/8" x 16 UNC x 1 3/4"
- 6x Hexagon screw 5x20
- 6x Nut 5mm, self-locking
- 12x Washer 5mm



The mounting of our saddlebag bracket is very simple:

The included „Bungee Nuts“ are mounted to the fender of the bike, so that the saddlebag, together with the bracket, is just clipped onto the nuts and can be secured with the lock. Our saddlebags have an aluminum plate sewed to the back where you can drill corresponding holes through, which fit the bracket. The position of the plate is palpable and, because of the border seams, clearly visible. At first please hold the saddlebag to your bike, to determine in which position the bag should hang later. After that, mark the drill-data with a pen on the backside of the bag, so that the bracket fits probably.

You can put six holes through the aluminum plate, normally four holes are sufficient. Then connect the bag to the bracket with the included screws and washers. You can freely choose the mounting height of the bracket because of the adequate size of the plate.

In the normal case you'll just have to remove the original screws and fix the Bungee Nuts to your fender bracket ("Fender-Struts"). Please check in the beginning which distance the screws at your bike have. With some bikes there are no holding screws present. Here you'll have to choose the corresponding distance (hole spacing: 150mm, bracket length: 170mm). However you'll have to drill holes by yourself and eventually have to tap. Or put the screws (maybe a slightly longer version) from the wheel side through the fender with the bracket to the outside, where you can then mount the Bungee Nuts. Now you can clip the bag easily on and lock the bracket.

