

BUFFALO BAG

HANDCRAFTED LEATHER



Mounting instruction saddlebag bracket

Harley Davidson Evo-Softail models (1992-2001) & HD Softail Twin Cam (2002-2017)

Scope of delivery:

1x bracket

2x bushing black M10 x 20

2x bushing black M10 x 25

1x bushing black M12 x 25

2x Allen Head Screw 8x30

2x Allen Head Screw 3/8x16x1 1/2"

2x Allen Head Screw 3/8x16x2 1/4"

2x Allen Head Screw 3/8x16x2 1/4"

2x Nut M8 self-locking

4x washer 10,5

4x washer 8,4

1x Allen Head Screw 1/2" x 13 UNC x 2"

1x washer 1/2"

1x hexagon Screw 1/2" x 16UNF x 1 3/4"

1x Allen Head Screw 3/8" x 2 1/2"



Figure 1: Please remove the screw of the left footrest. Please use the hexagon screw to mount the bracket. Please fix the new screw from the inside, together with the bracket and footrest.



Figure 2: For mounting on the upper frame tube sockets are supplied in 20 and 25mm spacing. With these connectors, the distance between the motorcycle / fender and bag holder can be changed. After assembly of the holder, the position of the bag is defined to the holder, marked out, 8mm holes in the back of the bag (aluminum plate), drilled and bolted together.

