

# Mounting instructions

## Bonnen guard Ford Ranger (2016-)



### Before mounting

- Please read this instructions before mounting to avoid possible damages to the car.
- Unpack the item and check if all parts are present.

### Part list

1. 1x Bonnet guard
2. 2x Metal clips broad
3. 2x Metal clips narrow with screw



# Mounting instructions

## Mounting steps

### Step 1:

Mount the broad metal clips (2) to both of the middle cutouts of the bonnet guard and the two narrow clips (3) to the outer cutouts. Put the corresponding screw, from the outside, through the respective hole in the bonnet guard to mount the clip to the underside of the bonnet guard. Just hand tighten the screws.



### Step 2:

Open the hood of your vehicle. Clamp the bonnet guard, with the mounting clips, under the edge of the hood and adjust it correctly. Put the white protective stripe between the clip and the hood to avoid scratching the surface. Now stick the two clips in the middle, with the already mounted car body tape, to the hood.



### Step 3:

Repeat step 2 for the two narrow clips on the outside edges of the hood. The clips are screwed to the underside of the hood for additional support. Tighten the screws firmly.



# Mounting instructions

## Mounting steps

### Step 4:

Now tighten the outer screws firmly to finish the mounting.

Note: The bonnet guard is not suited for cleaning in a carwash facility and has to be demounted before.

